

U1 Conveyor motor					
Inverter type J7			Inverter type J1000		
Description:	Parameter Nr:	U1 = Conveyor	Description:	Parameter Nr:	U1 = Conveyor
Init*	n01*	12*	Init*	A1-03*	2220*
Password	n01	1	Password	A1-01	2
Run command	n02	2	freq Ref selection	B1-01	2
Freq ref select	n03	6	Run command selection	B1-02	2
Select local mode	n07	1	Acc time	C1-01	2
Max freq in Hz	n09	50	Dec time	C1-02	2
Max Voltage	n10	230	Torque Compensation Gain	C4-01	0
Max freq output voltage	n11	50	Drive Duty Mode Selection	C6-01	0
Mid output freq	n12	2.5	carrier freq	C6-02	6
Mid output freq voltage	n13	24	Freq ref upper limits	D2-01	100
Min output freq	n14	1.3	Input voltage	E1-01	230
Min output freq voltage	n15	18	V/F control	E1-03	F
Acc time	n16	2	Max freq in Hz	E1-04	50
Dec time	n17	2	Max Voltage	E1-05	230
Freq ref upper limits	n30	100	Max freq output voltage	E1-06	50
Max current	n32	1.1	Mid output freq	E1-07	2.5
Multi-function output 1	n40	1	Mid output freq voltage	E1-08	24
Carrier freq	n46	4	Min output freq	E1-09	1.3
Timeover detection	n68	4	Min output freq voltage	E1-10	18
Memobus slave addres	n70	1	Max current	E2-01	1.1
Memobus baudrate	n71	2	Motor No-load current	E2-03	1
Parity	n72	2	Terminal MA/MB/MC function	H2-01	0
Send waiting time	n73	10	Memobus slave addres	H5-01	1
Memobus RTS control	n74	0	Memobus baudrate	H5-02	3
			Parity	H5-03	0
			Timeover detection	H5-04	3
			Communication Fault detection	H5-05	0
* Note: Factory reset.			Send waiting time	H5-06	10
			Memobus RTS control	H5-07	1
			Freq ref selection MEMOBUS	H5-13	0
			Automatic restart	L2-01	2

[illegible]

[illegible]