



INTRODUCTION

Thank you for purchasing your MPM screen printer.

This document contains information to answer all the frequently asked questions in relation to the installation of a MPM screen printer.

Section 1 – Important Installation Requirements

Section 2 – Machine Footprint

Section 3 – Training

If you have any further questions, please don't hesitate to contact your local MPM Customer Support Group.

US/Canada	
mtsc@itweae.com	800-737-8110, option 1 508-520-0083, Option 3 then Option 1
Mexico	
msupport@itweae.com	01-800-718-1614 (From US) 1-800-639-9574 (Direct) +52 (33) 33-65-6511
EUROPE	
mtsc@itweae.com	+1 508-520-0083 (US), Option 3 then Option 1
ASIA	
tsc.ap@itweae.com	+65 9674 7646

Thank you for your cooperation, may I take the opportunity of wishing you many years of quality production with your new MPM screen printer.

Sincerely,

Pat O'Brien
Vice President/General Manager

PREINSTALLATION CHECK LIST

Are you ready for Installation?

Item		Confirm
Pallet Jack/Forklift (Capable of lifting 3000 lbs (1360.7 kg))		<input type="checkbox"/> Yes <input type="checkbox"/> No
Main Supply Machine configured for 200-240V	_____ Voltage	<input type="checkbox"/> Yes <input type="checkbox"/> No
Pneumatic Supply 90 psi @ 4cfm (standard run mode) to 18cfm (Vacuum Wipe) (6.20 @ 1.9L/s to 8.5L/s), 12.7mm (0.5") diameter line	_____ Bar	<input type="checkbox"/> Yes <input type="checkbox"/> No
Print Medium (Solder Paste)		<input type="checkbox"/> Yes <input type="checkbox"/> No
Test Product (Stencil & Boards)		<input type="checkbox"/> Yes <input type="checkbox"/> No
Squeegees		<input type="checkbox"/> Yes <input type="checkbox"/> No

* For any questions or concerns on the above Installation Check List contact your local MPM Customer Support Group.

US/Canada	
mtsc@itweae.com	800-737-8110, option 1 508-520-0083, Option 3 then Option 1
Mexico	
msupport@itweae.com	01-800-718-1614 (From US) 1-800-639-9574 (Direct) +52 (33) 33-65-6511
EUROPE	
mtsc@itweae.com	+1 508-520-0083 (US), Option 3 then Option 1
ASIA	
tsc.ap@itweae.com	+65 9674 7646

Important Installation Requirements

It is critical both your facility and your employees are ready for the ITW EAE field service engineer's visit to install your new machine. Please review the list below and let us know if you have any questions. Failure in preparation may incur delays in the installation.

Utility and Environmental Requirements

Electrical Supply

- Electrical Power 200 - 240VAC ($\pm 10\%$) @ 50/60 Hz 20A,
- Single Phase

The machine is not supplied with an electrical plug. Please ensure one is made available when the machine is scheduled for installation.

Pneumatic Supply available at machines installation position.

- Air Supply 90 psi @ 4 cfm (standard run mode) to 18 cfm (vacuum wipe) (6.2 bar @ 1.9L/s to 8.5L/s)
- 12.7 mm (0.5") - Outer diameter, minimum of 9.5mm (3/8") - Inside diameter
- Machine is supplied with fitting that will accept .5" line

Other:

Weight:

Edison Printer (Models 100, 200, 300)

Crated	- 2194 lbs (995 kg)
Uncrated	- 1777 lbs (806 kg)

Height:

Edison Printer (Models 100, 200, 300)

Crated	- 83" (2159 mm)
Uncrated	- 62.55"(1589mm) at 37"-38" (940mm-965mm) transport height per IPC-SMEMA-9851

Depth:

Edison Printer (Models 100, 200, 300)

Crated	- 85" (2159 mm)
Uncrated	- 56.70" (1440 mm)

Width:

Edison Printer (Models 100, 200, 300)

Crated	- 56" (1422.4 mm)
Uncrated	- 50.40" (1280 mm)

Front and Rear Clearance (Minimum)

Edison Printer (Models 100, 200, 300)

20" (508 mm)

Ground Clearance

Edison Printer (Models 100, 200, 300)

Standard Height 3.4" (87 mm) to 4.4" (112 mm) corresponding to SMEMA transport conveyor height.

Dimensions and Floor Space Requirements

Install the Momentum in a clean, dust-free environment to ensure proper operation. The installation area should provide a clearance of 2 ft. (0.6 m) around to provide adequate space for service.

Uncrating

Install forklift blades under the printer base. Confirm that the forklift blades do not pinch any pneumatic or electrical lines and that they fully extend across the printer base.



ATTENTION


- ITW EAE recommends extended forks of 5 ft to 6 ft (152.4 cm x 182.8 cm) in length to ensure proper weight distribution when lifting the platform from the skid.
- Make certain that the forks have a total width/span of 5 ft (150 cm).
- Place the forks approximately one foot from the front legs (because the center of gravity is towards the front of the printer).
- The forklift must be capable of lifting 3000 lbs (1360.7 kg).






Installing Feet

Printer feet are installed as each shipping isolator is removed from the bottom of the printer. The feet are installed in the same location as the shipping isolator bolts. When assembling the feet to the Edison, the orientation of the level mount is such that the washer is on top (against the machine base), and the two hex nuts are below the washer. **NOTE:** For shipping purposes the washer is placed between the bottom of the foot and the hex nut, however when the machine is installed the washer needs to be placed between the bottom of the machine and the top of the hex nut.

Edison Series Machine Footprint







TRAINING AT INSTALLATION

As part of the Installation process, ITW EAE offers a complimentary “up and running” training program. This covers the basic operation, maintenance and programming of the printer and associated options.

- Paste, stencil and boards are required for test printing
- Required floor space needed for the machine
- Availability of upstream and downstream conveyors

Training Summary

Customer Start-Up Assistance Training

- The FSE (field service engineer) will provide maximum of eight hours of training for up to four process engineers*
 - If possible, use several different combinations of boards and stencils
- The FSE will provide a maximum of four hours of training for up to four operators*
- The FSE will provide a maximum of eight hours of training for up to four maintenance technicians*
- Verification alignment accuracy of the board and stencil
- The FSE will then demonstrate that the system performs to specification using the customer's production materials

***NOTE:** The customer's personnel are expected to devote the entire time to the training program. Hours not devoted by the customer may not be “banked” for later use.

Additional Training

A full range of training courses are available covering operation, maintenance and process. Courses are conducted at our ITW EAE headquarters in Hopkinton, MA.

For further information, including course descriptions and schedule please contact the Training Department or visit <http://www.itweae.com/services-and-support/americas>